

PIS-276



Installation Instruction

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

1. Carefully unpack your new fixture and lay out all the parts on clear area. Take care not to loose any small parts necessary for installation.
2. Secure the Mounting Strap to the Outlet Box by threading the two Outlet Box Mounting Screws through the Key Holes.
3. Connect the fixture wires to the Outlet Box wires as follows. Connect the White Fixture wire to the White Supply Wire, Connect the Black Fixture Wire to the Black Supply Wire. Make sure all Wire Connectors are secure and do not easily pull off with the slight tug. If there is on Green Ground Wire from the Outlet Box, connect the Fixture Ground Wire to the Universal Crossbar with the Green Grounding Screw provided.
4. Place the Wall Plate to the Mounting Strap and tighten with Mounting Screws
5. Raise the Shade to the Socket, tighten the Shade with Socket Ring to Socket.
6. Install proper light bulbs for your fixture. **DO NOT EXCEED THE SPECIFIED WATTAGE!** Return the power to the Outlet Box and test the fixture!! Your installation is now complete!!!

