## Shower Pan Must Be Set in Mortar Base for Proper Installation

