

Ph: (916) 638-2722 / Fax: (916) 638-2725

Installation Information

Item #P0180

Warranted only if installed by a qualified licensed plumber. Use Teflon paste or tape on all threaded connections.

- 1. Thread the shower head onto the shower arm or riser and hand tighten.
- 2. Turn on the water to check for leaks.

 If leaks occur, carefully tighten the head using a wrench (wrap with duct tape to protect the finish of the product).

